




CERES RANCH APPLICATION INSTRUCTIONS



HOW TO
APPLY



PRECAUTIONS



Do not use existing ear tag holes. Application of the CERES RANCH device in these existing holes could lead to damaging the ear.



Secondary Components are sharp. Please exercise caution when handling.



Use best biosecurity hygiene practices.



For CERES RANCH products only.



Once activated the sensor must remain in sunlight and within operating temperatures to maintain optimal use.




If you have any further queries, please visit our FAQ page cerestag.com/faq


PRODUCT COMPONENTS KEY

PRIMARY COMPONENT

PINS & TETHER



EAR TAG
REMOVAL
TOOL



CLAMP

APPLICATOR



ACTIVATION TOOL

CHARGING THE TAG




BEFORE APPLICATION

CHARGE THE PRIMARY COMPONENT

Before Activating ensure the CERES RANCH devices have had sufficient opportunity to charge.

CHARGING THE TAG




BEFORE ACTIVATION

CHARGE THE PRIMARY COMPONENT

When the **BLUE** LED light begins to flash quickly this indicates the tag is charging.

Once charging is complete the LED will change to a slow flash.



STEP 1

ACTIVATE THE PRIMARY COMPONENT

Use the Activation Tool and hold it flush against the Primary Component with the solar panels facing each other for at least 5 seconds.

The **RED** LED will flash slowly when properly activated.



STEP 2

STERILISE THE SECONDARY COMPONENT

Dip or spray the
Secondary Component
with antiseptic solution.

Use antiseptic solution
at recommended dilution.

Note:

Failure to do so may
cause irritation.

STEP 3


INSERT THE TETHER

Slide the Tether through the opening at the top of the Primary Component.

Slide the Tether horizontally until lip is over the tag and clicks. Push the rear of the Tether down until it clips into place.

Note:

There is only one way the Tether can slide through.






STEP 4

INSERT THE SECONDARY COMPONENT

Slide Secondary Component onto the Applicator Pin.





Note:

A spare Applicator Pin is located in the handle of the Applicator.

STEP 5

INSERT THE PRIMARY COMPONENT

Hold down the metal clamp and insert the Tether face down into the Applicator.





STEP 6

REMOVE OTHER TAGS

Remove all other tags* and ensure there is sufficient space in the ear for the CERES RANCH.

*this excludes regulatory tags




STEP 7

PREPARE TO APPLY

Locate the correct position in the upper-middle area of the ear between the two visible cartilage tendons.



Squeeze the Applicator handles firmly until there is an audible click. Then release



Note:

Solar panels must be facing outwards. Use left or right ear as per regulatory requirements.




*Visualisation will vary based
on Software Selection

DONE


Congratulations! Your
CERES RANCH device is
now active and applied.

To view your data log into
your Software Provider.

REMOVAL




Hook the Ear Tag Removal Tool over the Secondary Component and pull to cut.



Safely dispose of the Tether and Secondary Component.

Note:

For the health, safety and biosecurity of your animals DO NOT reuse Tether.



REUSE

Clean any debris from the Primary Component before reuse.

Repeat steps 1 to 7.

Note:

Ensure the RANCH Tags are charged in full sunlight before reuse.



**APPLICATION
INSTRUCTIONS
VIDEO** >

APPLICATION TRAINING VIDEO



**SCAN TO
WATCH**

 cerestag.com/application-instructions

CERES RANCH is a trademark of CERES TAG LTD, registered in Australia and other countries and regions.